


STACK CORROSION CONTROL ASSEMBLY

R:\CAD\DWG\A size deg sales manual-converted pdf-master bucket pdf-master CWEP\A-size submittals master deg & pdf\06 Components\comp-11230 spec-1.dwg -lk- 121807 11:03

Bul. #11230



OPERATING SEQUENCE:

STACK CORROSION CONTROL: (THERMOCOUPLE SENSING MINIMUM EXHAUST GAS TEMPERATURE LEAVING THE ECONOMIZER). DURING A COLD STARTUP THE DAMPER WILL BE POWERED TO THE 'MAXIMUM OPEN POSITION'. AS THE STACK TEMPERATURE EXITING THE ECONOMIZER RISES AND APPROACHES A PRESET POINT, THE DAMPER WILL BEGIN TO CLOSE TO THE 'NORMAL OPERATION POSITION'. AS THE PERCENT OF EXHAUST LOAD CONDITIONS FLUCTUATE TO LOWER OUTPUTS, THE DAMPER ACTUATOR WILL OPEN ACCORDINGLY TO MAINTAIN A MINIMUM PRESET OUTLET 'TEMPERATURE CONTROL POSITION'.

NOTES:

1. THE WIRING CONNECTION DIAGRAM IS AN EXAMPLE INDICATING THE BASIC ELECTRICAL COMPONENT DESIGN REQUIREMENTS.
2. ACTUATOR TYPES AND/OR ADDED CONTROLS CAN CHANGE WITHIN THE SUBMITTAL DRAWING PROCESS.
3. A SPECIFIC WIRING SCHEMATIC IS SUPPLIED IN CUSTOMER APPROVAL SUBMITTAL DRAWINGS.

